




Antonio Matese Caldaie srl
tel.055-958283



NOTA BENE PLEASE NOTE

- Posizionare il gdv nella posizione desiderata, quindi livellarlo tramite i piedini di regolazione piano.

Place the generator in the desired position, then level it through the flat adjustment feet.

- Estendere in alto la vasca telescopica il più possibile comunque per quanto consentito dalle connessioni idrauliche ed elettriche.

Extend the telescopic tank as high as possible, however, as far as permitted by the hydraulic and electrical connections.

- Essendo la vasca di tipo telescopico anticavitazione, le connessioni riguardanti la stessa dovranno essere spostate su di essa (ingresso acqua trattata e sfiato condensa così come il ritorno delle condense).

Since the tank is of the telescopic type anticavitation, the connections concerning the same must be moved on it (treated water inlet and condensate vent as well as the return of the condensate).

- Lo scarico convogliato in pressione di 3/4" maschio dovrà essere indirizzato in un pozzetto idoneo così come lo scarico non in pressione di 1" (scarico vasca di alimento e troppo pieno).

The discharge conveyed in pressure of 3/4" male must be directed in a suitable well as the discharge not in pressure of 1" (discharge food tank and too full).

